
# **ONICON Turbine Flow Meter Ordering Guide**





### II. INSTALLATION HARDWARE

Purchase of installation kit with the flow meter (insertion type) is **<u>strongly recommended</u>** to prevent installation problems. Installation hardware kits are listed immediately after insertion type flow meters.

# **III. CALIBRATION DATA**

ONICON flow meters are custom calibrated for each application. **Pipe size, material, flow range, etc. is required for all meters.** Use order form and fax or email directly to ONICON Incorporated.Order forms are provided in the product catalog and can be downloaded from ONICON's website. You may also use your own spread sheet, etc. to submit calibration data. Contact ONICON for assistance with calibration data questions.

#### **IV. PERIPHERAL DEVICES AVAILABLE**

Display Modules: Btu Meters:

See D-100, D-1200 and DB-1200 Series Display Modules See System-10 Series BTU Meters (different order forms for these)

## V. APPLICATION ASSISTANCE

Contact ONICON or your local sales representative for applications questions.



www.mvandc.com | sales@mvandc.com | Phone 877.566.3837 | Fax 925.407.2903